



Dorcy 41-2092 Headlamp Directions

A. Light Operation

1. Press once to light 3 LEDs.
2. Press twice to light 3 LEDs in half brightness mold.
3. Press thrice to light 3 LEDs in blinking mold.
4. Press again to switch off.
5. Repeat the above steps for the function you wish to operate.




B. To Wear Headlamp

1. Adjust the Band to the proper length and wear it on your head.
2. Hold the back lid of body and adjust it up and down for best angle. Max. angle adjustment / 80°.
3. Plug the power cord into DynaBox or the DC jack on the Battery Box for power as the Figure 2 shown.


C. Battery replacement

1. Take off the Lid as the Figure 3 indicated.
2. Load 3pcs "AA" size UM-3 batteries into the compartment in accordance with the mark of "-&+".
3. A "click" sound would be heard once Back Lid placed back to the Battery Box properly and replacement completed.



D. Power Charging through USB.

1. Plug the USB cord into the DC jack on the DynaBox and insert the other end to the USB jack on the computer.
2. Suggested Charging time - 3 hours



E. Crank Winding Operation

1. Lift up the crank as the Figure 5 shown.
2. Wind the crank clockwise or counterclockwise for 1~2Min.
3. Place the Crank back after use.



F. Notices

1. Always keep power switch at "OFF" position when not in use.
2. Do not light directly toward people's eyes.
3. Batteries replacement, Crank Winding or USB Charging, either way would be required when light turn dim.
4. To avoid product being damaged, take off batteries is recommended when not in use.
5. Spray resistant, never dip it in water to remain normal function.
6. Make sure the power switch remained at "OFF" position while charging.
7. Keep winding steadily by the same direction for every Crank charging.
8. The DynaBox is recommended to recharge after every use. For long-term storage, recharge it once in every 3 months.

G. Specifications

1. Built-in Lithium battery in DynaBox/LIR2450, 3.6V, 110mAh.
2. Battery Box/by 3pcs LR6 "AA" size batteries:
(Minimum Illumination/Distance: 1Foot/0.5LUX)
 - a. 3 LEDs power duration are up to 120H.
 - b. 3 LEDs in half brightness mode are up to 150H.
 - c. 3 LEDs in blinking mode are up to 140H.
3. Powered by Crank Winding/160rpm/per Min.
 - a. 3 LEDs power duration are up to 22Min.
 - b. 3 LEDs in half brightness mode are up to 32Min.
 - c. 3 LEDs in blinking mode are up to 25Min.
4. Powered by USB charging,
 - a. 3 LEDs power duration are up to 6H.
 - b. 3 LEDs in half brightness mode are up to 9H.
 - c. 3 LEDs in blinking mode are up to 8H.

