

BRINKMANN®
ARMORMAX™

Model # 809-1095-0



LED FLASHLIGHT

OPERATING INSTRUCTIONS

BATTERY REPLACEMENT: Install battery by first unscrewing tail cap. Remove battery insert. Insert battery with the positive (+) end toward head of flashlight. Make sure the spring is in place in tail cap. Replace tail cap by screwing in securely. Use alkaline batteries for maximum brightness and life. **Note:** Do not mix old and new batteries. Do not mix alkaline, standard (carbon - zinc), or rechargeable (nickel cadmium) batteries.

BULB REPLACEMENT: LED (Light Emitting Diode) never needs replacement.

PUSH BUTTON SWITCH: Depress switch in tail cap to turn flashlight On/Off.

1 YEAR LIMITED WARRANTY: The Brinkmann Corporation warrants the ARMORMAX™ LED Flashlight for one year from the date of purchase, against defects due to workmanship or materials to the original purchaser. This warranty does not cover: batteries, flashlights damaged due to normal wear, abuse, improper maintenance, battery leakage, disassembly of parts, scratches to the finish (considered normal wear), or attempted repair by anyone other than an authorized employee of Brinkmann. Brinkmann may elect to repair or replace damaged units covered by the terms of this warranty. This warranty extends to the original purchaser only and is not transferable or assignable to subsequent purchasers. Brinkmann requires reasonable proof of purchase. Therefore, we strongly recommend that you retain your sales receipt or invoice. To obtain repair or replacement of the ARMORMAX™ LED Flashlight, under the terms of this warranty, return flashlight (without batteries) and proof of purchase along with owner's name and address, postage pre-paid and insured to:

Brinkmann Lighting Products
Service Department
4215 McEwen Road
Dallas, TX 75244



Battery must be recycled
or disposed of properly.

Dry Location Use Only

The shape, style and overall appearance of this packaging and product are trademarks of The Brinkmann Corporation.

0409

BRINKMANN®
ARMORMAX™

Model # 809-1095-0



LINTERNA LED

INSTRUCCIONES DE OPERACION

REEMPLAZO DE BATERÍAS: Instale batería destornillando primero la tapa posterior. Quite el compartimento de la batería. Inserte la batería con el extremo positivo (+) hacia la cabeza de la linterna. Asegúrese de que el resorte esté colocado en la tapa posterior. Vuelva a atornillar firmemente la tapa posterior. Utilice las baterías alcalina para el brillo y la vida máxima. **Nota:** No mezcle las baterías viejas y nuevas. No mezcle las baterías alcalinas, estándares (carbón - zinc), o recargables (cadmio del níquel).

REEMPLAZO DE BULBO: El LED (Diodo Emisor de Luz) nunca necesita reemplazo.

INTERRUPTOR DE BOTÓN DE EMPUJE: Presione el interruptor en casquillo de la cola para girar la linterna encender/apagar.

GARANTÍA LIMITADA DE 1 AÑO: La Corporación Brinkmann garantiza la Linterna ARMORMAX™ LED un año a partir de la fecha de compra, que está libre de defectos de materiales o mano de obra al comprador original. Esta garantía no cubre: baterías, daño debido a uso normal, el abuso, mantenimiento impropio, baterías que se gotean, el desmontaje de partes, los rasguños (considerado uso normal), o reparación procurado por alguien no autorizado por Brinkmann. Brinkmann puede elegir a reparar o reemplazar las partes dañadas cubiertas por los términos de esta garantía. Esta garantía solo se extiende al comprador original y no es transferible ni assignable a compradores subsiguientes. Brinkmann requiere comprobante de compra razonable. Por lo tanto, nosotros recomendamos fuertemente que usted retenga su recibo de ventas o factura. Para obtener reparación o el reemplazo de el Linterna ARMORMAX™ LED, bajo los términos de esta garantía, regrese la linterna (sin baterías) con comprobante de compra junto con el nombre del dueño y dirección, el envío prepagado y asegurado a:

Brinkmann Lighting Products
Service Department
4215 McEwen Road
Dallas, TX 75244



Esta batería debe reciclarse
o debe ser desechada apropiadamente.

Uso en Lugares
Secos Solamente

⚠ ADVERTENCIA

Para prevenir daño a la vista, nunca mire directamente a la linterna cuando la luz está encendida. Nunca apunte luz en la cara de otra persona.

La forma, estilo y apariencia general de este envase y producto son marcas registradas de The Brinkmann Corporation.